



CABRETTE SWAG CHANDELIER 84"

ASSEMBLY AND INSTALLATION INSTRUCTIONS


ENGLISH

CABRETTE SWAG CHANDELIER 84" ENGLISH

CABRETTE SWAG CHANDELIER 84"

PARTS INCLUDED

- (A) Wire Nuts (3)
- (B) Mounting Screws (2)
- (C) Mounting Plate (1)
- (D) Canopy Screws (3)
- (E) Canopy (1)
- (F) Screwdriver (1)
- (G) Allen Wrench (1)
- (H) Metal Anchors (12)
- (I) Small Mounting Plates (6)
- (J) Wood Screws (12)
- (K) Set Screws (18)
- (L) Small Canopies (6)
- (M) Shade Holders (6)
- (N) Bulbs (6)
- (O) Shades (6) (packed separately)
- (P) Screws (12)



TOOLS NEEDED

- Drill (not included)
- Hammer (not included)

IMPORTANT

FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY OR INSTALLATION CAN RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. MOUNTING HARDWARE IS PROVIDED FOR MOUNTING DIRECTLY TO A JUNCTION BOX. UNIQUE OR ALTERNATIVE INSTALLATION METHODS MAY REQUIRE DIFFERENT MOUNTING HARDWARE, WHICH IS NOT INCLUDED. ALWAYS CONSULT WITH A LICENSED ELECTRICIAN BEFORE INSTALLATION.

INSTALLATION BY A LICENSED ELECTRICIAN IS STRONGLY RECOMMENDED.

IMPORTANT SAFETY FEATURES

BULBS

This fixture has been rated for six (6) 25-watt maximum Type G incandescent lightbulbs or six (6) 5.5-watt maximum LED lightbulbs. To reduce the risk of fire, do not exceed the recommended wattage.

DIMMER-SWITCH COMPATIBILITY

This fixture is dimmer-switch-compatible and may be used with either a forward-phase or reverse-phase dimmer switch.

WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information, go to www.P65Warnings.ca.gov.


STRANGULATION HAZARD

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

INSTALL SAFETY CABLE

1. Run safety cable through junction box and around structural member of building.
2. Wrap the safety cable around the saddle (a), and secure with u-bolt (b) and hex nuts (c).



ASSEMBLY AND INSTALLATION

SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.

1. Carefully remove all parts from the box and remove all plastic coverings. Place on a clean, soft surface.
2. Remove Mounting Plate (C) from Canopy (E) by unscrewing Canopy Screws (D) using Screwdriver (F).
3. Attach Mounting Plate (C) to the ceiling junction box and secure with Mounting Screws (B).
4. Remove Small Mounting Plates (I) from Small Canopies (L) by unscrewing Set Screws (K) using Screwdriver (F).
5. Place Small Mounting Plates (I) on the desired locations on the ceiling and use them as guides to mark Metal Anchor (H) positions.
6. Use a drill bit (not included) slightly smaller than Metal Anchors (H) to drill holes in the marked positions. Install Metal Anchors (H) in the holes using hammer (not included).
7. Place Small Mounting Plates (I) over Metal Anchors (H) and secure with Wood Screws (J).
8. Attach Small Canopies (L) to Small Mounting Plates (I) and secure with Set Screws (K) using Screwdriver (F).
9. Connect the safety cable as shown in the diagram on the previous page.
10. Loosen Screws (P) using Allen Wrench (G). Adjust the cord to the desired height, then tighten Screws (P) using Allen Wrench (G). See Diagrams 1 and 2.
11. Cut excess wires. Be sure to leave enough to reach the ceiling junction box.
12. Wrap the fixture ground wire (bare copper) around the green grounding screw and tighten. Connect the end of the fixture ground wire to the supply ground wire (usually green or bare copper) using a Wire Nut (A).
IT IS IMPERATIVE THAT THE FIXTURE IS GROUNDED.
13. Connect the fixture neutral wire (white) to the supply neutral wire (usually white) using a Wire Nut (A).
14. Connect the fixture hot wire (black) to the supply hot wire (usually black) using a Wire Nut (A).
DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS
15. Make sure all wire connections are tight, then carefully tuck into the junction box.
16. Install Canopy (E) to Mounting Plate (C) and secure with Canopy Screws (D) using Screwdriver (F).
17. Insert Bulbs (N) into the sockets.
18. Screw Shades (O) onto Shade Holders (M).
19. Assembly is complete.

ADJUSTING THE HANG HEIGHT

Any adjustments or alterations to the fixture, cord, or overall hang height that differ from those detailed on RH.com will void the Laboratory Listing and Approvals (UL, ETL, CSA, etc.). If the listing is voided, this means the product may no longer be safe for use as modified. RH does not recommend modifying the product.

CARE INSTRUCTIONS

Do not use polishes or cleaners on the fixture. Wipe clean with a soft, dry cloth.