

DEMARET PENDANT  
ASSEMBLY & INSTALLATION INSTRUCTIONS  
**ENGLISH**

# DEMARET PENDANT ENGLISH


## DEMARET PENDANT

### PARTS INCLUDED

- (A) Wire Nuts (3)
- (B) Mounting Strap (1)
- (C) Mounting Loop (1)
- (D) Mounting Screws (2)
- (E) Canopy (1)
- (F) Canopy Ring (1)
- (G) End Link (1)
- (H) Hanging Loop (1)
- (I) Shade Holders (1)
- (J) Bulb (1)
- (K) Shade (1)

### Extention Pole Kit (Sold Separately)

- (P-1) 6in. Rod
- (P-2) 12in. Rod
- (P-3) 18in. Rod
- (P-4) Coupling



**IMPORTANT: PLEASE READ**

PLEASE FOLLOW THE ASSEMBLY INSTRUCTIONS CLOSELY. IMPROPER ASSEMBLY OR INSTALLATION CAN RESULT IN PERSONAL OR PROPERTY DAMAGE. MOUNTING HARDWARE HAS BEEN PROVIDED FOR MOUNTING TO A WOODEN STRUCTURAL BEAM. UNIQUE OR ALTERNATIVE INSTALLATION TYPES MAY REQUIRE DIFFERENT MOUNTING HARDWARE, WHICH HAS NOT BEEN INCLUDED. ALWAYS CONSULT WITH A LICENSED ELECTRICIAN BEFORE INSTALLATION.

INSTALLATION BY A LICENSED ELECTRICIAN IS STRONGLY RECOMMENDED.

**IMPORTANT SAFETY FEATURES**

**BULBS**

This fixture has been rated for one (1) 40-watt maximum Type T lightbulb or one (1) 5.5-SBLED lightbulb. To avoid the risk of fire, do not exceed the recommended wattage.

**VAULTED CEILING COMPATIBILITY**

This fixture is vaulted-ceiling compatible, up to a maximum ceiling slope of 20 degrees.

**DIMMER SWITCH COMPATIBILITY**

This fixture is dimmer-switch compatible, and may only be used with a forward-phase dimmer switch.

**CEILING REINFORCEMENT**

Fixtures weighing 50 lbs. or more will require additional reinforcement above the ceiling where they are to be installed.

**WARNINGS**

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the fixture is fully assembled. To reduce the risk of fire, electrical shock, or personal injury, always turn off fixture and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when fixture is illuminated. Keep flammable materials away from lit bulb.

**WARNING: STRANGULATION HAZARD**

Keep cord at least 3 feet away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

**THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.**

**ASSEMBLY AND INSTALLATION**

**SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.**

1. Carefully remove all parts from the box and remove all plastic coverings.
2. Connect extension rods to the desired hanging height as shown in the following page.
3. A 1/4" IPS pipe must be installed in your ceiling. Install hicky on Mounting Strap (B) into ceiling 1/4 IPS PIPE.
4. Attach mounting Strap (B) to ceiling and secure with mounting screws (D) or other proper fasteners from your local hardware store. NOTE: THE MOUNTING PLATE MUST BE SECURED TO A STRUCTURAL MEMBER OF THE BUILDING, INDEPENDENT OF THE OUTLET BOX.
5. Connect the safety cable as shown in Fig. 1 on previous page.
6. Attach the fixture ground wire (green) to house ground wire (usually green or bare) in the junction box with the green grounding screw. Connect fixtures to corresponding house wire with a Wire Nut (A). Carefully tuck the wires back into the outlet box. IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
7. Connect the neutral wire (white) to the neutral outlet wire (usually white) with a Wire Nut (A) and wrap the connection with electrical tape.
8. Connect the hot wire (black) to the hot outlet wire (usually black) with a Wire Nut (A) and wrap the connection with electrical tape. DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.
9. Raise Canopy (E) to the affixed Mounting Strap (B) and secure with Canopy Ring (F).
10. Insert bulb (J) into the socket.
11. Place Shades (K) (packed separately) onto Shade Holders (I).
12. Restore power to outlet box and check operation of fixture.
13. Assembly is complete.

**CARE INSTRUCTIONS**

Do not use polishes or cleaners on the fixture. Wipe clean with a soft, dry cloth.

## DEMARET PENDANT ENGLISH

### ATTENTION: ADJUSTING THE HANG HEIGHT

Any adjustments or alterations to the fixture, cord, or overall hang height that differ from those detailed on RH.com will void the Laboratory Listing and Approvals (UL, ETL, CSA, etc.). If the listing is voided, this means the product may no longer be safe for use as modified. RH does not recommend modifying the product.

### HEIGHT ADJUSTMENT INSTRUCTIONS

1. Determine the desired hanging height and prepare the rods and couplers accordingly.
2. Feed the wires through the rods and couplers.
3. Thread the rods and couplers to the joint of the fixture body.
4. Feed the wires through the hanging loop and mounting loop.
5. Thread the hanging loop onto the top of one rod.
6. Join the hanging loop and mounting loop together using the link.

