



MANOTTI TORCHIERE FLOOR LAMP

ASSEMBLY & INSTALLATION INSTRUCTIONS


ENGLISH

MANOTTI TORCHIERE FLOOR LAMP

PARTS ENCLOSED

(A) 9-Watt Led Bulb (1)

(B) Lamp Body (1)



IMPORTANT: PLEASE READ**IMPORTANT SAFETY FEATURES****BULBS**

This lamp has been rated for one (1) 60-Watt Max. Type A Incandescent lightbulb or one (1) 9-Watt LED lightbulb (included). To avoid the risk of fire, do not exceed the recommended wattage.

DIMMER SWITCH COMPATIBILITY

This lamp is dimmer-switch compatible, and may only be used with a foot push-button dimmer switch.

WARNINGS

All wires are connected. When unpacking, be careful not to pull wires, as damage may result. Do not connect electricity until the lamp is fully assembled. To reduce the risk of wire, electrical shock, or personal injury, always turn off lamp and allow it to cool prior to replacing the lightbulb. Do not touch or look directly at the bulb when lamp is illuminated. Keep flammable materials away from lit bulb.

WARNING: STRANGULATION HAZARD

Keep cord at least 3 feet (92 cm) away from cribs, bassinets, and toddler beds. Keep out of reach of children under 3 years of age.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

ASSEMBLY AND INSTALLATION**SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE FUSE BOX OR CIRCUIT BREAKER PANEL.**

1. Carefully unpack all the contents from the box and remove wrapping from all parts.
2. Insert the recommended bulb (A) into the threaded socket, turning counterclockwise.
3. Place into proper outlet and test lamp.
4. Lamp is now ready for use.

CARE INSTRUCTIONS

Do not use polishes or cleaners on the lamp. Wipe clean with a soft, dry cloth.