

# AMADEO TIERED ROUND CHANDELIER 36" ASSEMBLY & INSTALLATION INSTRUCTIONS ENGLISH

### AMADES TIERED ROUND CHANDELIER 36" **K1** PARTS INCLUDED: (A) JUNCTION BOX, 50LBS/22.7KG MIN. FIXTURE RATED (NOT INCLUDED) (B) MOUNTING BOLTS (4 SETS, FOR CONCRETE CEILING ONLY) Α (C) WIRE NUTS (3) C1 (C1) CEILING PLATE (1) K2 В (C2) CEILING BOX (1) C2 (C3) BOLTS (2) **C**3 (D) QUICK LINK (6 MM) (1) -N (E1) EXTENSION ROD, 6" (15 CM) (1) ·I (E2) EXTENSION ROD, 6" (15 CM) (1) D (E3) EXTENSION RODS, 12" (30.5 CM) (2) (E4) EXTENSION RODS, 18" (45.5 CM) (2) **E1** (F) FIXTURE BODY (1) (G) GLASS RODS, 34.5 CM (560 + 20 EXTRA) E2 (G1) GLASS RODS, 26.5 CM (200 + 10 EXTRA) (H) BULBS (21 + 7 EXTRA) (I) LARGE ALLEN KEY (1) (J) SET BOLTS (13 + 3 EXTRA) **E3** (K1) SAFETY CABLE (1) (K2) SAFETY CABLE (1) (L) SMALL ALLEN KEY (1) J **E4** F G1 G

#### IMPºRTANT: PLEASE READ

PLEASE F9LL9W THE ASSEMBLY INSTRUCTIONS CLOSELY.
IMPROPER ASSEMBLY OR INSTALLATION CAN RESULT IN
PERSONAL OR PROPERTY DAMAGE. MOUNTING HARDWARE
HAS BEEN PROVIDED FOR MOUNTING TO CONCRETE CEILING.
UNIQUE OR ALTERNATIVE INSTALLATION TYPES MAY REQUIRE
DIFFERENT MOUNTING HARDWARE, WHICH HAS NOT BEEN
INCLUDED. ALWAYS CONSULT WITH A LICENSED ELECTRICIAN
BEFORE INSTALLATION.

INSTALLATION BY A LICENSED ELECTRICIAN IS STRONGLY RECOMMENDED.

IMPORTANT SAFETY FEATURES

#### **BULBS**

THIS FIXTURE HAS BEEN RATED FOR TWENTY-ONE (21) 25-WATT MAXIMUM E12 TYPE T6 INCANDESCENT BULBS (TWENTY-ONE 25-WATT E12 TYPE

T6 INCANDESCENT BULBS INCLUDED) OR TWENTY-ONE
(21) 6-WATT

MAXIMUM E12 TYPE T6 LED BULBS (NOT INCLUDED). TO AVOID THE RISK

OF FIRE, DO NOT EXCEED THE RECOMMENDED WATTAGE.

**VAULTED-CEILING COMPATIBILITY** 

THIS FIXTURE IS VAULTED-CEILING COMPATIBLE, UP TO A MAXIMUM CEILING SLOPE OF 15 DEGREES.

DIMMER-SWITCH COMPATIBILITY THIS FIXTURE
IS DIMMER-SWITCH COMPATIBLE AND MAY BE
USED WITH A

FORWARD- OR REVERSE-PHASE DIMMER SWITCH.

CEILING REINFORCEMENT FIXTURES
WEIGHING 50 LBS/22.7KG OR MORE
WILL REQUIRE ADDITIONAL
REINFORCEMENT ABOVE THE CEILING
WHERE THEY ARE TO BE INSTALLED.

#### WARNINGS

ALL WIRES ARE CONNECTED. WHEN UNPACKING, BE CAREFUL NOT TO PULL WIRES,

AS DAMAGE MAY RESULT. DO NOT CONNECT ELECTRICITY UNTIL THE FIXTURE IS

FULLY ASSEMBLED. TO REDUCE THE RISK OF FIRE, ELECTRICAL SHOCK, OR PERSONAL

INJURY, ALWAYS TURN OFF FIXTURE AND ALLOW IT TO COOL PRIOR TO REPLACING THE

LIGHTBULBS. DO NOT TOUCH OR LOOK DIRECTLY AT THE BULBS WHEN FIXTURE IS

ILLUMINATED. KEEP FLAMMABLE MATERIALS AWAY FROM LIT BULBS.

#### WARNING: STRANGULATION HAZARD

KEEP CORD AT LEAST 3 FEET (91CM) AWAY FROM CRIBS, BASSINETS, AND TODDLER BEDS.

KEEP OUT OF REACH OF CHILDREN UNDER 3 YEARS OF AGE.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.

#### INSTALL SAFETY CABLE


1. REMOVE THE NUT LOCKER A & B BY LOOSENING THE

SET SCREW FROM THE CEILING SAFETY CABLE BEFORE INSTALLATION. 2. INSERT THE CEILING SAFETY CABLE THROUGH THE

NUT LOCKERS AS SHOWN

3. FASTEN THE NUT LOCKER A WITH SET SCREW/BOLT.

4. FASTEN THE NUT LOCKER B WITH SET SCREW/BOLT.



#### ASSEMBLY AND INSTALLATION

## SHUT 9FF THE MAIN ELECTRICAL SUPPLY FR9M THE FUSE B9X 9R CIRCUIT BREAKER PANEL.

- 1. CAREFULLY REMOVE ALL PARTS FROM THE BOX AND REMOVE ALL PLASTIC COVERINGS.
- 2. TURN 9FF POWER TO JUNCTION BOX (A) WHERE THE FIXTURE WILL BE INSTALLED.
- 3. LOOSEN THE BOLTS (C3) AND REMOVE THE CEILING PLATE (C1) FROM THE CEILING BOX (C2).
  - HAVE A PROFESSIONAL CONTRACTOR REINFORCE THE CEILING. ATTACH
- 4. THE SAFETY CABLE (K1) TO CEILING BEAM THROUGH THE JUNCTION BOX (A), THEN ATTACH THE SAFETY CABLE TO THE FIXTURE ON THE CEILING WITH THE NUT LOCKERS.
  - ATTACH THE CEILING PLATE (C1) TO THE CEILING WITH MOUNTING
- 5. BOLTS (B). ATTACH THE CEILING BOX (C2) TO CEILING PLATE (C1), THEN FASTEN THE BOLTS (C3).
  - ATTACH THE EXTENSION RODS (E4, E3, E2, AND E1) TO THE FIXTURE
- 6. BODY (F) AND SECURE WITH SET BOLTS (J). IF THE EXTENSION RODS ARE NOT ALIGNED, PLEASE LOOSEN THE SET BOLTS AND LOOSEN THE EXTENSION A LITTLE BIT UNTIL THE EXTENSION RODS ARE ALIGNED, THEN TIGHTEN THE SET BOLTS (J).
  - FEED WIRES AND SAFETY CABLE (K2) THROUGH EXTENSION RODS (E4,
- 7. E3, E2, AND E1) TO COME OUT FROM THE TOP OF THE EXTENSION ROD (E1).
  - MOVE UP THE FIXTURE BODY (F) TO CEILING PLATE (C1), THEN ATTACH
- 8. THE COLLAR OF THE EXTENSION ROD (E1) TO THE CEILING PLATE (C1) WITH QUICK LINK (D).
  - MOVE DOWN THE CEILING BOX (C2) FROM THE CEILING PLATE (C1),
- 9. AND FEED WIRES AND SAFETY CABLE THROUGH THE CEILING BOX (C2).
- 10. ATTACH THE SAFETY CABLE (K2) FROM FIXTURE AROUND U-BRACKET OF CEILING PLATE AND SECURE WITH NUT LOCKERS AS ILLUSTRATED.

  CAREFULLY INSPECT THE FIXTURE WIRES. QNE IS THE GROUND WIRE
- 11.

  (MARKED W. THE SECOND IS THE NEUTRAL WIRE (MARKED WITH N). THE THIRD WIRE IS THE LIVE/HOT WIRE (MARKED WITH L).
- 12. CONNECT THE FIXTURE GROUND WIRE TO THE POWER SUPPLY GROUND WIRE WITH WIRE NUTS (C).
  - NOTE: IT IS IMPERATIVE THAT THE OUTLET BOX IN YOUR HOME BE PROPERLY GROUNDED.
  - CONNECT THE FIXTURE NEUTRAL WIRE TO THE POWER SUPPLY NEUTRAL
- 13. WIRE WITH WIRE NUTS (C).
  - CONNECT THE FIXTURE LIVE/HOT WIRE TO THE POWER SUPPLY LIVE/HOT
- 14. WIRE WITH WIRE NUTS (C).
  - CAUTION: DO NOT REVERSE THE HOT AND NEUTRAL
  - CONNECTIONS, AS SAFETY WILL BE COMPROMISED.
- 15. MOVE THE CEILING BOX (C2) UP TO THE CEILING PLATE (C1), THEN FASTEN THE BOLTS (C3).
  - FASTEN BULBS (H) INTO THE LAMPHOLDERS.

- 17. INSERT THE GLASS RODS (G & G1) INTO THE BODY (F) FROM BOTTOM TIER TO TOP TIER. TO ENSURE THE BALANCE OF THE FIXTURE BODY DURING GLASS ROD INSTALLATION, PLEASE INSERT THE GLASS RODS IN A BALANCED WAY ON THE OPPOSITE SIDE.
- 18. RESTORE POWER TO THE JUNCTION BOX AND TEST FIXTURE.
- 19. ASSEMBLY IS COMPLETE.


#### CARE INSTRUCTIONS

DO NOT USE POLISHES OR CLEANERS ON THE FIXTURE. WIPE CLEAN WITH A SOFT, DRY CLOTH.


REVISION 08-14-2023

#### HEIGHT ADJUSTMENT INSTRUCTIONS

1. FEED THE WIRES AND SAFETY CABLE (K2) THROUGH EXTENSION ROD (E1), THEN FASTEN EXTENSION ROD (E1) TO THE FIXTURE BODY (F) AND SECURE WITH THE SET BOLTS (J).



2. 9R, FEED THE WIRES AND SAFETY CABLE (K2) THROUGH THE EXTENSION RODS (E2, E3 OR E4) AND SECURE WITH THE SET BOLTS (J), THEN FASTEN THE EXTENSION ROD (E1) TO EXTENSION RODS (E2, E3 OR E4).



#### ATTENTION: ADJUSTING THE HANG HEIGHT

ANY ADJUSTMENTS OR ALTERATIONS TO THE FIXTURE, CORD, OR OVERALL HAND HEIGHT THAT DIFFER FROM THOSE DETAILED ON RH.COM WILL VOID THE LABORATORY LISTING AND APPROVALS (UL, ETL, CSA, ETC.). IF THE LISTING IS VOIDED, THIS MEANS THE PRODUCT MAY NO LONGER BE SAFE FOR USE AS MODIFIED. RH DOES NOT RECOMMEND MODIFYING THE PRODUCT.